




HG033 USER MANUAL

hygger aquarium clip-on light



Please read this manual carefully before using and follow strictly in accordance with the manual.

1. PRODUCT PARAMETER


MODEL	6W	9W	14W
INPUT VOTAGE	AC100-240V	AC100-240V	AC100-240V
OUTPUT VOTAGE	DC5V	DC12V	DC12V
LED QUANTITY	13PCS 10White+2Blue+1Red	24PCS 18White+4Blue+2Red	36PCS 24White+8Blue+4Red
LIGHT SIZE (WITHOUT BRACKET)	5.7*1.77*0.39inch	5.7*1.77*0.39inch	12.87*1.77*0.39inch
APPLICATION	8~12inch	12~16inch	16~21inch
POWER CORD	5.2ft	6.2ft	6.2ft


2. METHOD OF APPLICATION


- (1) Unpack the box and check if the light and other accessories are included. If missing parts, please contact the seller.
- (2) Clamp the clip onto the edge of the aquarium and secure it with the screws. The Holder must be secured firmly enough to prevent the light from falling into the water.
- (3) You can assemble it in the front or side part. Then adjust the height of the lamp body and the angle of the light by adjusting the hose
- (4) Connect the power supply with the light, then plug it in. Ensure a drip loop is created before the outlet as shown in the warning label.

3. FUNCTION

A. Press  button to turn on or turn off the light.

B. Press  button to choose the lighting mode,
White & Blue & Red → Blue & Red → White → White & Blue & Red in turn.

C. Press  button to adjust the bright of light for 8 stage like
100%-77%-55%-32%-10%-32%-55%-77%-100%

D.Press  button to set the lighting time 6H、 9H、 12H or turn off timer.

6H timer: Orange indicator is on, the led light will be off 6 hours later, then it will lights up at the same time the next day.

9H timer: Green indicator is on, the led light will be off 9 hours later, then it will lights up at the same time the next day

12H timer: Red indicator is on, the led light will be off 12 hours later, then it will lights up at the same time the next day.


Memory function: If power failure, the light will turns on at the same brightness and spectrum once restore.

4. ATTENTION:

- ✓ Please read this manual carefully before using and follow strictly in accordance with the manual.
- ✓ Please keep the light away from water, because the light is not waterproof.
- ✓ Please keep the light away from flammable items, in order to avoid accidents.
- ✓ Please unplug the power and contact the seller when the light is abnormal working, ****OPENING WILL VOID WARRANTY****
- ✓ Please unplug the power before maintenance.
- ✓ Please mind that the temperature range for the light is 23~113°F.

5. PACKAGE INCLUDED:

- 1× Led Light
- 1×AC/DC adaptor
- 1×User manual

 **6. WARNING:** To avoid possible electrical shock, do not immerse the light in water. If the switch falls into the water, or otherwise becomes wet, do not touch it until you have unplugged it. Basic safety precautions should be observed including the following:

1. Read and follow this user manual strictly.
2. DANGER-To avoid possible electric shock, special care should be taken. For each of the following situations,do not attempt to repair yourself; Return the light to an authorized service facility for service or discard the light.

- A. If the light falls into the water, do not touch it. First unplug it, then retrieve it. If electrical components of the light get wet, unplug the light immediately.
- B. Carefully examine the light after installation. It should not be plugged in if there is water on parts not intended to be wet.
- C. Do not operate the light if it has a damaged cord or plug, if it is malfunctioning or if it is dropped or damaged in any manner. The power cord of this light cannot be replaced, if the cord is damaged, the light should be discarded.
- D. To avoid the possibility of the light plug getting wet, position the aquarium stand and tank to one side of a wall-mounted receptacle to prevent water from dripping onto the receptacle or plug. A “drip loop”, shown in the figure below, should be arranged by the user for each cord connecting the light to the receptacle. The “drip loop” is the part of the cord below the level of the receptacle or the connector. If an extension cord is used, to prevent water traveling along the cord and coming in contact with the receptacle. If the plug or receptacle does get wet, DO NOT unplug the cord. Disconnect the fuse to the circuit breaker that supplies power to the light. Then unplug and examine for the presence of water in the receptacle.

3. Close supervision is necessary when the light is used near children.

4. To avoid injury, do not contact moving parts or hot parts and so on.


5. Make sure the light is securely installed before operating it.

6. Read and observe all the important notices on the light.

7. If an extension cord is necessary, a cord with a proper rating should be used. A cord rated for less amperes or watts than the appliance rating may overheat. Care should be taken to arrange the cord so that it will not be tripped over or pulled.

8. The light is intended FOR HOUSEHOLD USE ONLY.

9. SAVE THIS USER MANUAL



7. DISPOSAL

Do not dispose this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary. This product must not be disposed together with the domestic waste. This product has to be disposed at an authorized place for recycling of electrical and electronic appliances. By collecting and recycling waste, you help save natural resources, and make sure the product is disposed in an environmental friendly and healthy way.



8. CONTACT INFORMATION

E-mail: service@hygger-online.com

Website: www.hygger-online.com